KICKPI K2B ??????

1. sudo□□□□□ `/etc/wpa_supplicant.conf` □□□□□□□□ “□□ ”
2. ```
   ctrl_interface=/var/run/wpa_supplicant
   ap_scan=1
   update_config=1

   network={
           ssid="Liang"
           psk="wifi1234"
           key_mgmt=WPA-PSK
   }
   ```
3. □□ `wpa_supplicant -D nl80211 -i wlan0 -c /etc/wpa_supplicant.conf -B` □□□□□□
   1. □□□□□□□□ `/var/run/wpa_supplicant`
   2. □□□□□□□□ `/var/run/wpa_supplicant/wlan0`
4. □□ `dhclient wlan0` □□ wifi
5. □□□□□□□□□□□□□ `vi /etc/network/interfaces` □□□
6. ```
   auto wlan0
   allow-hotplug wlan0
   iface wlan0 inet dhcp
   wpa-conf /etc/wpa_supplicant.conf
   ```

Revision #8
Created 2025-06-21 10:24:21 UTC by Colin
Updated 2026-04-29 07:34:06 UTC by Colin